




BOSCH

SMS 2100 – 0 730 103 500–EU1
SMS 2100 – 0 730 103 507–ZA1
SMS 2100 – 0 730 103 517–I1

GESCHIRRPÜLGERÄTE
Standgeräte



Ident-Nummern-Konstante
3740

51 1552/00
EU1, I1, ZA1
Gebrauchsanweisung
(D,GB,F,I,NL,DK,P,E)
51 1381/00
Aufstellanleitung

1) 04 2085/04
Set

2) 04 2105/03
Set

3) 01 9177/02
Set

4) 08 3406/41
bis FD 6408
08 4061/41
ab FD 6409

5) 05 1827/17
bis FD 6410
05 5056/17
ab FD 6411

6) 20 2255/17
bis FD 6410
20 2793/19
ab FD 6411


7) 04 4783/12
bis FD 6411
05 3961/07
ab FD 6412



BOSCH

SMS 2100 – 0 730 103 500–EU1
SMS 2100 – 0 730 103 507–ZA1
SMS 2100 – 0 730 103 517–I1

GESCHIRRSPÜLGERÄTE
Standgeräte




Ident-Nummern-Konstante
3740


- 1) 08 0781/02 Set
- 2) 02 5067/01 Set
- 3) 01 9204/02 Set
- 4) 20 1073/22 3000 W EU1, ZA1
20 2256/22 2300 W I1
- 5) 14 0283/37 220 V, 50 Hz
02 5606/05 Relais
- 6) 14 0175/37 220 V, 50 Hz
08 0783/16 10µF

160526-5/2

Ident-Nummern-Konstante
 3740



Ident-Nummern-Konstante
 3740



- 1) 08 3459/13
Set
- 2) 08 3460/13
Set
- 3) 20 2017/17
bis FD 6410
20 2795/16
ab FD 6411
- 4) 20 2018/17
bis FD 6410
20 2796/16
ab FD 6411
- 5) 11 1325/09
bis FD 6410
11 4960/09
ab FD 6411



BOSCH

SMS 2100 - 0 730 103 500-EU1
SMS 2100 - 0 730 103 507-ZA1
SMS 2100 - 0 730 103 517-I1

GESCHIRRPÜLGERÄTE
Standgeräte

Ident-Nummern-Konstante
3740

- 1) 01 9202/01/4
- 2) 11 0668/07
Set
- 3) 05 1287/03
Set
- 4) 20 0794/33
bis FD 6408
20 2683/33
ab FD 6409

