

website : <http://www.LGService.com>
e-mail : <http://LGService.com/techsup.html>

WASHING MACHINE SERVICE MANUAL

CAUTION

READ THIS MANUAL CAREFULLY TO DIAGNOSE TROUBLE
CORRECTLY BEFORE OFFERING SERVICE.

**MODEL : WD(M)-14101(6)FD
WD(M)-16101(6)FD
WD-16200FD
WD-16210FD**



CONTENTS

1. SPECIFICATION.....	3
2. FEATURES & TECHNICAL EXPLANATION	4
3. PARTS IDENTIFICATION	7
4. INSTALLATION.....	8
5. OPERATION	11
5-1. FUNCTION.....	11
5-2. HOW TO USE WASHER	12
6. WIRING DIAGRAM / PROGRAM CHART	20
7. TROUBLESHOOTING.....	21
7-1.BEFORE PERFORMING SERVICE	21
7-2.QC TEST MODE.....	21
7-3.HOW TO KNOW THE WATER LEVEL FREQUENCY.....	21
7-4.ERROR DISPLAY	22
8. ERROR DIAGNOSIS AND CHECK LIST	24
8-1. DIAGNOSIS AND ANSWER FOR ABNORMAL OPERATION	24
8-2. FAULT DIAGNOSIS AND TROUBLESHOOTING	27
9. DISASSEMBLY INSTRUCTIONS	33
10. EXPLODED VIEW AND PARTS LIST	
10-1. THE EXPLODED VIEW OF CABINET ASSEMBLY	40
10-2. THE EXPLODED VIEW OF CONTROL PANEL AND DISPENSER ASSEMBLY	41
10-3. THE EXPLODED VIEW OF DRUM AND TUB ASSEMBLY	42
※ APPENDIX (Replacement parts list)	

1. SPECIFICATION

ITEM	WD(M)-14101(6)FD, WD(M)-16101(6)FD, WD-16200FD,WD-16210FD	
POWER SUPPLY	220-240V~, 50Hz	
PRODUCT WEIGHT	65kg	
ELECTRICITY CONSUMPTION	WASHING	230W
	SPIN (1400rpm)	440W
	DRAIN MOTOR	38W
	WASH HEATER	2000W
REVOLUTION SPEED	WASH	45rpm
	SPIN	1600 rpm : No spin/400/600/800/1000/1200/1400/1600 rpm
		1400 rpm : No spin/400/600/800/1000/1200/1400 rpm
OPERATION WATER PRESSURE	0.3-10kgf/cm ² (30-1000kPa)	
CONTROL TYPE	Electronic	
WASH CAPACITY	7kg	
	Synthetic (4kg), Wool (2kg), Hand Wash (2kg), Delicate (3kg), Quick 30(5kg)	
DIMENSION	600mm(W) × 600mm(D) × 850mm(H)	
WASH PROGRAM	Whites, Coloureds, Synthetic, Wool, Hand Wash, Delicate, Quick 30	
RINSE	Super, Normal, Rinse Hold	
DOOR SWITCH TYPE	Bi-Metal type	
WATER LEVEL	9 steps (by sensor)	
RESERVATION	From 3 hours to 19 hours	
SENSING OF THE LAUNDRY AMOUNT	Adapted	
FUZZY LOGIC	Adapted	
DISPLAY OF THE REMAINING TIME	Adapted	
ERROR DIAGNOSIS	9 items	
POWER AUTO OFF	Adapted	
CHILD LOCK	Adapted	
AUTO RESTART	Adapted	
RAPID	Adapted	


2. FEATURES & TECHNICAL EXPLANATION

2-1.FEATURES




■ Jumbo drum

LG's jumbo drum can wash about 40% more load than conventional washing machine. A bigger drum improves the wash performance.




■ More economical by Intelligent Wash System

Intelligent Wash System detects the amount of load and water temperature, and then determines the optimum water level and washing time to minimize energy and water consumption.




■ Direct Drive system

The advanced Brushless DC motor rotates the Drum directly without belt and pulley.




■ Child-Lock

The Child-Lock system has been developed to prevent children from pressing any button to change the program during operation.



■ Low noise speed control system

By sensing the amount of load and balance, automatical distributes load evenly to minimize the spinning noise level.




■ Auto Restart

Although the washing machine is turned off by a power failure, it restarts automatically where it stopped when power is supplied again. And it will be the same the machine is unplugged and is plugged in again.

■ Wide LCD

- Its Liquid Crystal Display (LCD) Panel gives you all information with animated pictures in detail to its User-Friendliness.
- It shows various text and graphical expressions.
- It is easy to glance and get detailed explanations about careful points before washing.
- Washer's manual can be downloaded easily by use of a big LCD panel.
- It shows all progress step by step through moving/animated graphical images. This lets you know what's going on in washing machine.




■ Digital Design

- New Millennium digital washer's Digital Design is so convenient of use, also you have images of the high class.
- Its user-friendliness facilitates with dial-type control button selection and ergonomics design.
- It is totally a digital washer with the highest shine and the best values.



2-2.DETERMINE WASHING TIME BY FUZZY LOGIC

To get the best washing performance optimal time is determined by sensing of water temperature, selected washing temperature and laundry amount.




2-3.WATER LEVEL CONTROL

- This model adopts a pressure sensor which can sense the water level in the tub.
- Water supply is stopped when the water level to the preset level, then the washing program proceeds.
- Spinning does not proceed until the water in the tub reduces a certain level.



2-4.THE DOOR CAN NOT BE OPENED

- While program is operating.

3. PARTS IDENTIFICATION



■ ACCESSORIES






Inlet hose (2 EA) * (Repair) : Hot/Cold (2 EA) Wrench

4. I N S T A L L A T I O N

- 1 Before servicing ask the customer what the trouble is.
- 2 Check the adjustment (power supply, etc.) of the appliance.
- 3 Check the troubles referring to the troubleshooting chart.
- 4 Decide service steps referring to disassembly instructions.
- 5 Then, service and repair.
- 6 After servicing, operate the appliance. Do not see whether it works.


■ S T A N D A R D I N S T A L L A T I O N

The appliance should be installed as follows.


RE MO VE TH E TR A N S I T BO L T S	I N S T A L L TH E A P P L I A N C E O N F L A T A N D F I R M S U R F A C E	A H O R I Z O
<ul style="list-style-type: none"> • Remove the transit bolts (4E A): with supplied spanner. • Keep the transit bolts and spanner for future use. • Insert the provided 4 caps into the hole. 		<ul style="list-style-type: none"> • Turn the leveling feet to set the appliance horizontal.  <ul style="list-style-type: none"> • The appliance goes up rotating the feet clockwise. • The appliance comes down rotating the feet counterclockwise.

■ H O W T O C O N N E C T I N L E T H O S E


- Check that the rubber washer is inside of the valve connector.
- Connect the inlet hose firmly to prevent



■ C O N N E C T D R A I N H O S E




• Make sure that the hose is not twisted. Avoid submerging the end of the




※ The drain hose should be placed under 100cm from the floor.

■ C O N N E C T P O W E R P L U G




• Connect the power plug to the wall outlet.



Avoid connecting several electric
It may be the cause of a fire.


TEST OPERATION

1 Preparation for washing.




- Connect the power plug to the outlet.
- Connect the inlet hose.

2 Press the Power button.




3 Press the Start/Pause button.




- In case of coloured programs...

6 Check the water heating.




- Press the Temp button and the present temperature will be displayed.

5 Check the heating turn.



- Check if the drum rotates clockwise.

4 Check automatic reverse




- Check if water is supplied through the door.

7 Check drain and spin.


- Turn Wash and Rinse after pressing Start/Pause button and start the machine again.
- Check drain and spin.

8 Power off and open door



- Power off and then press Power.
- Check if the door can be opened after 3 minutes.

9 Water removal



- Water removal is needed during these remaining water by pulling out the hose cap.

5. O P E R A T I O N

5-1 . F U N C T I O N

■ Recommended program according to the laundry type

Program	Fabric Type	Proper Temp. (Option)	Washing (Option)	Load	Water in Liter	Energy in KWh	Time in Minutes
White	First check if this machine is (white cotton towels and shirts...)	if laundry washable (40°C in 60°C)	Main + (Pre) + (Soak) ...)	7.0kg	95	2.9	165
				5.0kg	88	2.4	165
				2.0kg	75	1.8	125
Coloured	For fast garments (shirts, night pajamas...) and lightly soiled cotton (underwear...)	40°C (Cold)	Main + (Pre) + (Soak)	7.0kg	75	0.72	122
				5.0kg	65	0.7	122
				2.0kg	52	0.6	112
Synthetic	Polyamide, Polyester.	40°C (Cold)	Main + (Pre) + (Soak)	3.5kg	60	0.5	89
				2.0kg	48	0.4	
Delicate	Delicate laundry easily damaged (curtains...)	30°C (Cold)	Main	3.0kg	60	0.5	64
				1.0kg	48	0.3	
Wool	Machine washable woolens with new wool only.	30°C (Cold)	Main	2.0kg	52	0.3	62
				1.0kg	48	0.2	
Hand Wash	Hand washed delicate and laundry.	30°C (Cold)	Main	2.0kg	52	0.03	56
				1.0kg	48	0.01	
Quick 30	Laundry type is the same in cotton and synthetic.	30°C (Cold)	Main	5.0kg	48	0.3	30
				2.0kg	40	0.2	


*Pre Wash : If the laundry is soiled, recommended.

Pre Wash is available in Whites, Coloureds, Synthetic.
 *Water Temperature : Select the water temperature to the manufacturer's label or instructions when laundering.

*Eco : By selecting Eco function, the water temperature is reduced.
 So you can economize in your consumption of heating.

NB. You can select Eco function when the temperature is high (over 60°C) in Synthetic.

5-2 . H O W T O U S E W A S H E R



① Coloureds automatically selected upon power on.

- Press **Power** (⏻) button to start.
- Press **Start/Pause** (▶||) button.
- Initial condition
 - *Wash : Main wash*
 - *Rinse : 3 times*
 - *Spin : 1600 rpm (1400 rpm)*
 - *Water temperature : 40°C*
 - *Program : Coloureds*

② Manual Selecting


- Press **Power** (⏻) button to start.
 - Select the conditions which you want to **Program Dial** by turning a dial.
 - Press **Start/Pause** (▶||) button.
- For selecting the each conditions, please refer to the page13~page18*

③ Beep on/off

- The beep on/off function can be set **Option** and **Help** buttons simultaneously more 5 seconds.
 - The beep on/off function can be set at any time and it is a failure occur.
- Also the beep on/off function works when power is off.

④ Auto half load

- Auto half load saves you time and money when washing. The washing machine is fitted with a self adjusting water level sensor.
- This system enables the machine to use the amount of water needed for the laundry in relation to the particular load.




- (1) Button : Power (⏻) (4) Button : Option (7) Button : Reset
 (2) Dial : Program (5) Child lock (8) Button : Help
 (3) Button : Start/Pause (6) Button : Time Delay

5-2 -1 . Power

① Power

- Press **Power** (⏻) button to turn power on and off.
- To cancel the Time Delay (6) button should be pressed.



② Initial Program

- When **Power** (⏻) button is pressed, the **Coloureds** program is ready for start. And the other initial conditions as follows.
- So, if you want to advance into the program, just press **Start/Pause** (▶||) button and the power washer will start.

Initial program

- [WD(M)-16101(6)FD, WD-16210FD, WD-16200FD]
 -Coloureds Program / Main wash / Normal Rinse / 1600 rpm / 40°C
- [WD-14101(6)FD]
 -Coloureds Program / Main Wash / Normal Rinse / 1400 rpm / 40°C

5-2 -2P. r o g r a m m e

① P r o g r a m s e l e c t i o n

- When **Start/Pause**(▶||) button is pressed, program is automatically selected.
- How to select program and course (option)
 1. Press **Power**(⏻) button.
 2. Rotate **Program Dial** button and select desired program. (Whites, Coloureds, Synthetics, Delicate, Wool, Hand Wash, Quick 30, Rinse+Spin, Spin only, Drain only)
 3. Press **Program Dial** button.
 4. Rotate **Program Dial** button and select desired course. (Wash, Rinse, Spin, Soak, No Wash)
 5. Press **Program Dial** button and select desired course option.
 6. Press **Program Dial** button.
 7. Press **Start/Pause**(▶||) button

- By rotating **Program Dial** button, the program is selected as follows: Whites, Coloureds, Synthetics, Delicate, Wool, Hand Wash, Quick 30, Rinse+Spin, Spin only, Drain only

Regarding to the laundry type for each program Please refer to the page 11.


② C o u r s e

- Whites, Coloureds, Synthetics, Delicate, Wool, Hand Wash, Quick 30, Rinse+Spin, Spin only, Drain only.

5-2 -3. S t a r t / P a u s e

① S t a r t

- This **Start/Pause**(▶||) button is used to start or restart the wash cycle.




② P a u s e

- If temporary stop of wash, **Start/Pause**(▶||) button.
- When in pause, the power is turned off automatically after 10 minutes.

5-2 -4. W a s h

- By rotating and **Program Dial** button, the wash type is selected.

- Main Wash, Pre Wash + Main, Soak, No Wash



① M a i n W a s h

- **Main Wash** course is available for lightly or normally soiled laundry.

② P r e W a s h + M a i n W a s h


- If the laundry is heavily soiled, **Pre Wash + Main Wash** course is effective.
- **Pre Wash** is available in **Whites, Coloureds** and **Synthetic** program.

③ S o a k

- Operations about 60 minutes for **Main Wash** course.
- **Main Wash** course is for **Soak Wash** course without drain.
- **Soak Wash** is available in **Whites, Coloureds** and **Synthetic** program.

5-2 -5. Rinse

- By rotating and pushing the **Program Dial** button, the rinse type is selected.
 - Normal, Super, Rinse Hold, No rinse*



① Normal

- Whites / Coloureds / Synthetic performs 3 Rinses
- Wool / Hand Wash /Delicate / Quick 30 performs 2 Rinses

② Super

- Normal + 1 more rinse time.
- Use **Super rinse** when additional rinsing is desired to remove extremely soiled loads.

③ Rinse Hold

- Is selected by rotating **Program Dial** button to the position. When selected, this function leaves clothes in the washer; suspended in the water after spin.
- To proceed through to a **Start/Pause** button press the **Start/Pause** button.
- If you want to drain only, the spin course.

5-2 -6 Spin


- By rotating and pushing the **Program Dial** button, the spin speed is selected.

[WD(M)-14101(6)FD]

- No spin / 400 / 600 / 800 / 1000 / 1200 / 1400

[WD(M)-16101(6)FD, WD-16200FD, WD-16210FD]

- No spin / 400 / 600 / 800 / 1000 / 1200 / 1400 / 1600



WD (M)-1 61 01 (6)FD , WD -1 62 00FD
WD -1 62 1 0FD

① Spin selection

- Spin speed is available according to the program as follows.

-Whites / Coloureds [WD (M)-1 61 01 (6)FD , WD -1 62 00FD , WD -1 62 1 0FD]

1 600▶No Spin▶400▶600▶800▶1 000▶1 2 00▶1 400

[WD (M)-1 41 01 (6)FD]

1 400▶No Spin▶400▶600▶800▶1 000▶1 2 00▶1 400

-Synthetic / Wool 1 000▶No Spin▶400▶600▶800

-Delicate / Hand Wash 800▶No Spin▶400▶600

-Quick 30 [WD (M)-1 61 01 (6)FD , WD -1 62 00FD , WD -1 62 1 0FD]


400▶600▶800▶1 000▶1 2 00▶1 400▶1 600▶No Spin

[WD (M)-1 41 01 (6)FD]

400▶600▶800▶1 000▶1 2 00▶1 400▶No Spin

5-2 -7W a t e r T e m p .

- By rotating and **Program Dial** button, the water temperature can be selected.
- Cold / 30°C / 40°C / 50°C / 60°C / 95°C



① W a t e r T e m p e r a t u r e


- Water temperature can be selected as below according to the program:

- whites	95°C → 40°C → 50°C → 60°C
- Coloureds & Synthetic	40°C → 50°C → 60°C → Cold → 30°C
- Wool & Delicate & Quick 30	30°C → 40°C → Cold
- Hand Wash	Cold → 30°C → 40°C

For the more detailed information, please refer to the page 11.

5-2 -8O p t i o n

- If you use to select **Bio/Eco/Time Save/Crease care**, (you can wash more effectively).
- By pressing **Option** button, only one option function can be selected.
 1. Press **Power** () button.
 2. Select the desired Program.
 3. Press **Option** button.
 4. Select the desired function by pressing the **Start/Pause** () button to the



① Bio ()

- If you want to eliminate protein stains (milk, soy, blood, etc.) and pressing the Program Dial button.
- NB.** You can select Bio function when the temperature is higher than 30°C. **Whites, Coloureds, Synthetic.**

② Eco ()

- By selecting Eco function, the water temperature is reduced and can economize in your consumption of energy.
- NB.** You can select Eco function when the temperature is higher than 30°C. **Whites, Coloureds, Synthetic.**

③ Time save ()


- This option can be used to reduce the time of a wash program.
- This function is not available with **Quick 30** program.

④ Crease care ()

- If you want to prevent crease, select this function with spin.


5-1 -9C hild lock

If you choose to lock the buttons on the control panel to prevent tampering, this function may be selected.




① Child lock


- Child lock can be set by pressing the **Option** and **Time Delay** buttons simultaneously.



- When child lock is set, all buttons are inoperable.
- To deactivate child lock, press the **Option** and **Time Delay** buttons again.



- To change to the desired program, whilst in child lock mode:
 1. Press and hold the **Option** and **Time Delay** button together once again.
 2. Press **Start/Pause** (▶||) button.
 3. Select the desired program by pressing the **Start/Pause** (▶||) button again.




- The child lock can be set at any time and it is automatically cancelled when power is restored. Also child lock works when power is off.

5-2 -1 0. Time Delay

① Time Delay

Preparing washing before starting “Time Delay.”

- Turn on the water tap.
- Load laundry and close the door.
- Place the detergent and fabric softener drawer.



• How to “Time Delay”

1. Press **Power** (⏻) button.
 2. Turn **Program dial** button to select the program or course (option).
 3. Press **Time Delay** button.
 4. Press **Time Delay** button or **Program Dial** button to set the desired time.
 5. Press **Start/Pause** (⏸) button to begin (start).
- If **Time Delay** button is pressed, “3:00” is displayed. The maximum delayed time is 16 hours and the minimum time is 3:00 hours.
 - Each press of **Time Delay** button advances time on delay by one hour.
 - To cancel the time delay, press **Power** (⏻) or **Reset** button.
 - Time delay exists from the present to the completion of washing process (Wash, Rinse, Spin).
 - *According to the condition of water supply and temperature, the delayed time and the actual washing time may vary.*

5-2 -1 1 . Display

① Washer process display

- Displayed washer process with words and animations.
- Each course, word background gets darker and current process gets lighter.
- When touching the button, screen gets lighter and darker in sequence.

② Special function display

- When Child lock is used, it is displayed.
- When time delay is selected, it shows the remaining time.

③ Self diagnose display

- If the washer encounters a fault during operation, it displays the error code as follows:
 - “IE” : Water inlet trouble
 - “DE” : Drainage trouble
 - “UE” : Unbalanced load
 - “dE” : Door is not closed
 - “tE” : Water temperature trouble
 - “FE” : Problem of overflowing water
 - “PE” : Water pressure sensing error
 - “CE” : Overload in motor
 - “LE” : Overload in motor

If this error letters are displayed, please refer to the troubleshooting page 44~45 and follow the guide.

④ Completion of washing

- When washing is completed, the word (Finished) is displayed on the Multi Display.




⑤ Time left

- During washing cycle, the remaining washing time is displayed.
- Default time of each program.
 - Whites : around 2 hours and 45 minutes
 - Coloureds : around 2 hours and 2 minutes
 - Synthetic : around 1 hours and 29 minutes
 - Wool : around 1 hour and 2 minutes
 - Hand Wash : around 56 minutes
 - Delicate : around 1 hour and 4 minutes
 - Quick 30 : around 30 minutes
- The washing time may vary by the amount of laundry, water, washing conditions.
- If an unbalanced load is detected or if the suds removing process is extended. (Max. increasing time is 45 minutes.)


5-2 -1 2. Reset

- During Pause status, use this button to cancel what you are washing, rinse and spin etc.
- When a user presses this button, the screen will return to the main screen.
- Use this button also to go back to main screen after using Help.



5-2 -1 3. Help

- The Help function offers a variety of detailed information including Program explanation, Button explanation, Washing tips, Troubleshooting guide (before you call), view last message.
- This section of the user guide will demonstrate how to easily navigate the main areas of the topics. From there, you will easily be able to find your search for finding laundry information.




6. W I R I N G D I A / B R O M G R A M C H A R T

* Water Supply : W/S * Intermittent Spin : I/S * Disentangle : D/T

CYCLE STEP COURSE P Time (SEC)	Washing										Rinse								Spin		A U T O O F F E N D 20	Normal Working Time (Hour:Minute)								
	Pre			Main				Normal (Hold)				Extra (Hold)				Drain	Spin	D/E												
	W/S	Washing	Drain	W/S	Washing	Staycooling	W/S	Washing	W/S	Rinsing	Drain	1	2	3	4				W/S	Rinsing			Drain	W/S	Rinsing	Drain				
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20			21	22	23	24	25	26	27	28
Whites	120	60	300	120	40	3 TIMES																							20	About 2:45
Coloreds	120	60	300	120	56																								20	About 2:02
Synthetic	120	60	300	120	29																								20	About 1:29
Wool	120	60	300	120	17																								20	About 1:02
HandWash	120	60	300	120	16																								20	About 56
Delicate	120	60	300	120	20																								20	About 1:04
Quick30	120	60	300	120	10																								20	About 30
Washing	120	60	300	120	23																								20	About 1:10
Rinsing					56																								20	About 39
Rinsing Hold																													20	About 39
Spin																													20	About 15
Washing + Rinsing	120	60	300	120	23																								20	About 1:48
Washing + Spin	120	60	300	120	23																								20	About 1:17
Rinsing + Spin					56																								20	About 53

- * Basic Cycle
- * Optional Cycle
- * Pre-Setting Time : Water Supply - 120 sec.
Drain - 60 sec.
- * ~ Time for varies as the temperature or the amount of laundry
- * For Wool or Synthetic course only 650 rpm is operated
- * Shower Rinsing : Rinsing time is 20 sec
- * Basic time is minute in washing chart
- * The actual program time can be varied with the load amount, water temperature or ambient temperature



7. TROUBLE SHOOTING

7-1 .BEFORE PERFORMING SERVICE

- Be careful of electric shock or disconnecting the parts while troubleshooting.
- Voltage of each test point is 240V-242V while applying an electric current.

7-2 .QC TEST MODE .


- ① Press **Rinse**, and **Spin** button simultaneously.
- ② Power supply on with pressing upper two button. Then buzzer sound.
- ③ Press the **Start/Pause** button as follows.

[Press the **Start/Pause** button more 4 times until stop spinning]

Pressing number of [Start/Pause] button	Checking Point	Display	Status
None	All lamps turn on	12:55	
1 time	Clockwise spin (right)	40-50	Drum rpm (About 40-50)
2 times	Low speed Spin	53-65	Drum rpm (About 53-65)
3 times	High speed Spin	40-60	Drum rpm (About 40-60)
4 times	Inlet valve for prewash operation	5-65	Water level
5 times	Inlet valve for main wash operation	5-65	Water level frequency (2)
	Hot inlet valve in case of hot water fill		
6 times	Inlet valve for main wash operation	5-65	Water level
7 times	Counterclockwise spin (left)	40-50	Drum rpm (About 40-50)
8 times	Heater is in operation	Water temperature	Water temperature
9 times	Draining pump operation		Water level
10 times	Auto off operation		

7-3. HOW TO KNOW THE WATER LEVEL FREQUENCY










* Press **Rinse** and **Spin** button simultaneously.






● The digits means water level frequency (10 Hz)
 ex) 241 : Water level frequency = 241 Hz
 = 24.1 kHz

7-4. ERROR DISPLAY.











- If you press the Start/Pause button when **FE** is displayed, the machine will go to pause status.
- In case **FE, OE, dE**, if the error is not resolved within 20 sec. In the if the error is not resolved within 40 min, the power will be automatically cut off. But in the case of **ne, power** will not be turned off.







	ERROR	SYMPTOM	CAUSE
1	WATER INLET ERROR	 	<ul style="list-style-type: none"> ○ Water has not reached to the pre-set level inlet valve operated, or water has not reached level within 25 min.
2	IMBALANCE ERROR		<ul style="list-style-type: none"> ○ Load is too small. ○ The appliance is tilted. ○ Laundry is gathered to one side. ○ Non-distributable things are put into the drum.
3	DRAIN ERROR	 	<ul style="list-style-type: none"> ○ Water has not drained enough within 10 min.
4	OVERFLOW ERROR		<ul style="list-style-type: none"> ○ Water is automatically being pumped out when water is in the tub.
5	SENSOR PRESSURE S/W ERROR		<ul style="list-style-type: none"> ○ The sensor pressure switch is out of order.
6	DOOR OPEN ERROR	 	<ul style="list-style-type: none"> ○ The Start/Pause button is pressed with the door open. ○ The door switch is out of order.



	ERROR	SYMPTOM	CAUSE
7	HEATING ERROR		<ul style="list-style-type: none"> The THERMISTOR is out of order.
8	CURRENT ERROR		<ul style="list-style-type: none"> MAINPWBASEMBLY is out of order <ul style="list-style-type: none"> Replace the MAINPWBASEMBLY Winding in the STATORASEMBLY is short-circuited <ul style="list-style-type: none"> Replace the STATORASEMBLY
9	LOCK ERROR		<ul style="list-style-type: none"> The connector (3-pin, male, with 3 pins) in the LEAD WIRE ASSEMBLY is not connected to the connector (3-pin, female) in the STATORASEMBLY. <ul style="list-style-type: none"> Reconnect or repair the connector The electric contact between the LEAD WIRE ASSEMBLY male, natural in color, and the STATORASEMBLY female is unstable. <ul style="list-style-type: none"> Reconnect or repair the contact in the connector The LEAD WIRE ASSEMBLY base is short-circuited between the STATORASEMBLY and MAINPWBASEMBLY. <ul style="list-style-type: none"> Repair the damaged (open-circuited) the ASSEMBLY The hall sensor is out of order/defective. <ul style="list-style-type: none"> Replace the STATORASEMBLY

8. E R R O R D I A G N O S I S A N D C H E C K L

8-1 .D I A G N O S I S A N D A N S W E R F O R A B N O R M A

SYMPTOM	GUIDE FOR SERVICE CALL
<p>NO P O W E R</p>	<div style="display: flex; justify-content: space-between;"> <div style="width: 60%;"> <p>Is the power plug connected firmly to 220-240V~ outlet?</p> <p style="text-align: center;">YES</p> <p>Power failure? or Breaker opened? Is the outlet controlled by a switch?</p> <p style="text-align: center;">NO</p> <p style="text-align: center;">Visit to check</p> </div> <div style="width: 35%; text-align: right;">   </div> </div>
<p>W A T E R I N L E T T R O U B L E</p> <div style="text-align: center; margin: 10px 0;">  </div> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>Caution</p> <p> No feeding. Check....</p> </div>	<div style="display: flex; justify-content: space-between;"> <div style="width: 60%;"> <p>Is  displayed?</p> <p style="text-align: center;">YES</p> <p>Is the tap opened?</p> <p style="text-align: center;">YES</p> <p>Is the tap frozen?</p> <p style="text-align: center;">NO</p> <p>Is the water supply shut-off?</p> <p style="text-align: center;">NO</p> <p>Is filter in the inlet valve clogged with foreign material?</p> <p style="text-align: center;">NO</p> <p style="text-align: center;">Visit to check</p> </div> <div style="width: 35%; text-align: right;">     <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Clean the filter of inlet valve clogged with foreign material?</p>  </div> </div> </div>

SYMPTOM	GUIDE FOR SERVICE CALL
<p>◦ DOOR OPEN ERROR</p>  <div data-bbox="170 571 495 728" style="border: 2px solid black; padding: 5px;"> <p>Caution</p> <p>▶ Door is opened. Close the door.</p> </div>	<p>Did you press Start/Pause button when the door is open?</p> <p>YES → Close the door</p>  <p>NO</p> <p>Visit to check</p> <p>Check if the door switch is O.K</p>
<p>◦ DRAIN TROUBLE</p>  <div data-bbox="170 1086 495 1254" style="border: 2px solid black; padding: 5px;"> <p>Caution</p> <p>▶ No draining. Check...</p> </div>	<p>Is  displayed?</p> <p>YES</p> <p>Is the debris filter clogged with foreign material such as pins, coins in the filter?</p> <p>YES → Clean the filter</p>  <p>NO</p> <p>Is the drain hose frozen with water, or crushed?</p> <p>NO</p> <p>Visit to check</p> 


SYMPTOM	GUIDE FOR SERVICE CALL
<p>◦Suds overflow from the appliance. (In this condition, wash and spin do not operate normally)</p>	<div style="display: flex; justify-content: space-between;"> <div style="width: 60%;"> <p>Is low-sudsing detergent for the drum washing machine used?</p> <p style="text-align: center;">YES</p> <p>Is the proper amount of detergent used as recommended?</p> <p style="text-align: center;">YES</p> <p style="border: 1px solid black; border-radius: 15px; padding: 5px;">Recommend to reduce the amount of detergent.</p> <p>* This appliance has the automatic suds sensing operates under much suds condition for good preventing overflow. * When much suds are sensed, the suds remove as drain, water in pipe, and it is out rotating the drum.</p> </div> <div style="width: 35%; text-align: center;">  <p>LOW-SUDSING DETERGENT</p> </div> </div>
<p>◦No effect of softener</p>	<div style="display: flex; justify-content: space-between;"> <div style="width: 60%;"> <p>Is softener put in the correct compartment of the drawer?</p> <p style="text-align: center;">YES</p> <p>Is the drawer closed during wash?</p> <p style="text-align: center;">YES</p> <p>Is the softener cap clogged?</p> <p style="text-align: center;">YES</p> <p style="border: 1px solid black; border-radius: 15px; padding: 5px;">Explain how to use softener. Clean the compartment for softener</p> </div> <div style="width: 35%; text-align: center;">  <p>Compartment for softener</p> </div> </div>
<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid gray; border-radius: 5px; padding: 2px 5px; margin: 2px;">FE</div> <div style="border: 1px solid gray; border-radius: 5px; padding: 2px 5px; margin: 2px;">CE</div> <div style="border: 1px solid gray; border-radius: 5px; padding: 2px 5px; margin: 2px;">FE</div> <div style="border: 1px solid gray; border-radius: 5px; padding: 2px 5px; margin: 2px;">LE</div> <div style="border: 1px solid gray; border-radius: 5px; padding: 2px 5px; margin: 2px;">EE</div> <div style="border: 1px solid gray; border-radius: 5px; padding: 2px 5px; margin: 2px;">LE</div> </div>	<p style="border: 1px solid black; border-radius: 15px; padding: 10px; text-align: center;">Visit to check</p>

8-2 . F A U L T D I A G N O S I S A N D T R O U B L E S H O O T


C A U T I O N

1. Be careful of electric shock or disconnecting the parts while trouble
2. First of all, check the connection of each part terminal with wiring d
3. If you replace the MA IN P W B o n S E M B L Y, c o n n e c t t h e c


NO POWER




NO WATER SUPPLY



DETERGENT DOES NOT FLOW IN



SOFTENER DOES NOT FLOW IN



Is water supplied?

NO


Refer to
NO WATER SUPPLY

YES

Are receptacles correctly connected to the INLET VALVE ASSEMBLY? Check the wiring and the dispenser.

NO

YES




Is softener put in the correct compartment?

NO

Put it in the correct compartment.

YES




Is the softener cap clogged?

YES

Clean the cap and drawer.

ABNORMAL SOUND



Is the motor bolt loosened?

YES

Fix the bolt tightly.


NO

Is there friction noise from the STATOR ASSEMBLY or ROTOR ASSEMBLY?

YES


Replace the STATOR ASSEMBLY or ROTOR ASSEMBLY.

HEATING WITHOUT WATER



When pressing Time Delay, Reset and Program Dial buttons at the same time after draining, is the water level frequency 252 or more?
 When pressing Time Delay, Reset and Program Dial buttons at the same time while wash, is the water level frequency between 230-243?


Replace the
DRY SENSE SWITCH ASSEMBLY



Checking voltage between two POWER button is the 40V voltage?


Replace the
MAIN PWB ASSEMBLY

DRAIN MALFUNCTIONING




Is the drain hose twisted or bent?

Repair the
DRAIN HOSE ASSEMBLY




Is the impeller of the drain pump blocked by foreign material?

Remove the foreign material



Is the connector disconnected?

Reconnect or repair the connector




Is the coil of the drain pump (resistance of coil is 90~200Ω) cut-off?

Repair the
DRAIN PUMP ASSEMBLY

When checking voltage between (1, 2) on spinning, is the 40V voltage as the figure?

Repair the
MAIN PWB ASSEMBLY

WASH HEATER TROUBLE




When checking the voltage between connectors (①, ②) during whites washing, Is the voltage 220 - 240V ~?

NO

Replace the MAIN PWB ASSEMBLY

YES




After power off, is the resistance of wire (RED-YELLOW) connectors between 10Ω~30Ω?

YES

Normal

NO




After power off and the heater terminal is disconnected, is the resistance 10~30Ω?

NO

Replace the HEATER ASSEMBLY

HEATING CONTINUOUSLY ABOVE THE SETTING WATER TEMPERATURE




When disconnect the connector (1) on the, MA IN P W B ASSEMBLY, is the resistance of the natural connector (3) Blue to (6) (Seky, blue) between 0.1~0.18Ω (100~0°C)?

NO

Replace the THERMISTOR (632 2 F R2 046C)

YES




When checking the THERMISTOR on the tub is the THERMISTOR loosened above the rubber?

YES

Push the THERMISTOR tightly to the rubber.


SPIN TROUBLE



Check on the spinning, is the frequency of the water level 248 or more. The frequency is checked by pressing the Time Delay, Reset and POWER Program Dial buttons at the same time on the program.

Check the S.PRESSURE SWITCH ASSEMBLY HOSE (Pressure Switch Assembly) or the HOSE, replace the S.PRESSURE SWITCH ASSEMBLY or the HOSE.


YES



When pressing Time Delay, Reset and POWER buttons at the same time after power is turned on, is the drum spinning at low speed?

Yes, Normal, press the Start/Pause button 2 times, is the drum spinning at low speed?


NO



Is it disconnected, or disassembled? [Red:3pin (1), NA:6pin (2)]


Correct the connector

NO



Check the motor connector, is the resistance of the terminal same as the figure?

MOTOR TERMINAL (1)



Resistance of terminal:

①~② / ②~③ / ③~①: Abo $\Omega \pm 15\Omega$

Replace the STATOR ASSEMBLY (4417FA1994E)


YES

Replace the MAINPWBASEMBLY


9. D I S A S S E M B L Y T I P S

*Be sure to unplug the machine out of the outlet before disassembling.


CONTROL PANEL ASSEMBLY



- ① Unscrew 2 screws on the back of the top plate.
- ② Pull the top plate backward and upward.




- ① Disconnect the control panel from the machine.
- ② Pull out the drawer and unscrew 2 screws from the top of the control panel.
- ③ Push 2 upper hooks down and pull out the control panel.




- ① Disconnect the power board from the control panel by unscrewing 7 screws.

DISPENSER ASSEMBLY




- ① Disassemble the TOP PLATE ASSEMBLY.
- ② Pull out the drawer slightly upward.
- ③ Unscrew 2 screws.



- ① Disassemble hose clamps and hoses.
- ② Disassemble the ventilation bellows from the tube.

INLET VALVE ASSEMBLY



- ① Disconnect the wiring connector.
- ② Unscrew 2 screws from the back.

*When reconnecting the connector


*Cold only model

VA L VE #1 (MA IN)	W h i t e d / B l a c k - B l a c k
VA L VE #2 (P R E)	Gr a y / W h i t e - B l a c k

*Cold and Hot model


VA L VE #1 (MA IN)	W h i t e d / B l a c k - B l a c k
VA L VE #2 (P R E)	Gr a y / W h i t e - B l a c k
VA L VE #3 (H O T)	B l u e / R e d - B l a c k

MAIN PWB ASSEMBLY




- ① Remove the backcover.
- ② Unscrew 3 screws.
- ③ Disassemble the FILTER ASSEMBLY.
- ④ Pull the MAIN PWB ASSEMBLY as shown.

LOWER COVER



- ① Open the lower cover CAP by using the lower cover in the arrow direction unscrewed.


DOOR ASSEMBLY




- ① Open the door completely.
- ② Remove the two screws from the h

※ When removing the **STEADYDRY** is necessary to hold the **BRACKET** that **CABINET COVER**.


GASKET



- ① Take apart the **ASSEMBLY** (cabinet).
- ② Unscrew 2 screws from the **CABINET**
- ③ Open the lower cover cap and uns
- ④ Take apart the **LOWER COVER**.




- ① Disassemble the **CONSTRUCTION** (Refer to page 55)
- ② Unscrew all the screws on the upper
- the **CABINET COVER**.




- ① Take apart the **ASSEMBLY**
- ② Make sure that the drain hole of the
- beneath when reassembling the **G**
- ※ Refer to the arrow mark on the **TUB C**

ROTOR ASSEMBLY, STATOR ASSEMBLY, FRICTION DAMPER ASSEMBLY



(R O T O R A S S E M B L Y)


- ① Remove the BACK COVER.
- ② Unscrew the bolt to pull out the ROTOR.



(S T A T O R A S S E M B L Y)

- ① Disconnect the wiring connector.
- ② Unscrew 6 bolts from the STATOR.
- ③ Remove the BODY FRAME.
(Only 1400 or 1450)


*Note : Hook of connector (1) is on the




(F R I C T I O N D A M P E R A S S E M B L Y)

- ① Pull out the HINGE, pressing its snap.
- ② Do not use the pulled out HINGE again. It may be taken off during operation.


■ Clean the drain pump filter



Open the lower cover (1) by using a coin.




Remove any foreign material from the pump (2) in the bucket (3).




After cleaning, turn the pump filter (3) to prevent water flow into the floor. When water does not flow any more, turn the pump filter (3) to the original position and close the lower cover (1) open to the left.

DRAIN PUMP ASSEMBLY



- ① Remove PUMP HOSE .
- ② Remove BELLOWS ..
- ③ Remove CAP (Remaining Hose.)
- ④ Disconnect the wiring .
- ⑤ Unscrew 3 screws
- ⑥ Remove the DRAIN PUMP ASSEMBLY.

HEATER ASSEMBLY




- ① Loosen the M6 heater nuts to pull out the HEATER ASSEMBLY.

CAUTION


When mounting the HEATER ASSEMBLY, be sure to insert the HEATER ASSEMBLY into the bottom of the tub.

THERMISTOR




- ① Pull it out by holding the THERMISTOR RAG.
- * If it is pulled by the wire, it may be broken.
- ② When mounting the THERMISTOR RAG, be sure that it is got back tight to the bushing.

SWITCH ASSEMBLY, DOOR LOCK



- ① Take apart the ASSEMBLY (cabinet) and release the GASKET.
- ② Unscrew 2 screws holding the DOOR ASSEMBLY.
- ③ Disconnect the door lock from the w

WHEN FOREIGN MATERIAL IS STUCK BETWEEN DRUM AND TUB




- ① Remove the HEATER ASSEMBLY.
- ② Remove the foreign material (wire, etc.) by inserting a long bar through the hole.

1 0. E X P L O D E D V I E W A N D P A R T L I

1 0-1 . T H E P A R T L I S T O F C A B I N E T A S S E M B L Y


○ : Service Part

⋯ : Non-Service Part



1 0-2 THE EXPLODED VIEW OF SCOPE INSTRUMENT ASSEMBLY

- : Service Part
- (dashed) : Non-Service Part



1 0-3 TH E E X P L O D E D D R U M & T U B S E M B L Y

○ : Service Part

○ : Non-Service Part

