Service Instruction no. 1 / 27.03.2013

Repair instruction for the door liner damage in the switch action area

ARCTIC
Product Development

27.03.2013




Repair steps:

To make the reparation is necessary to following the next steps:

1. Please to give order for the following part in ARCTIC – "Push Plate Switch" – Drawing no. 4627100100. The order like spar part will be made on the drawing no.

4627100100.

The part drawing is:



2013 ARCTIC Product Development

2. To repair the door please follow next 3 steps:





Step 1 Step 2



Step 3

