






Gebrauchsanweisung
59 1422



- 1) 17 3862
- 2) 17 2274
- 3) 17 3879
- 4) 18 8194
- 5) 18 9083
- 6) 49 0673





TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS			
Verdichter/Compressor/Compresseur/Compresor Typ/Type/Tipo Förderleistung/Delivery/Debit/Aspiración l/h Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm Hi/aux.	Danfoss NLX15 KK		
Klappe Therm./Thermostat/Termostat Typ/Type/Tipo Reglerstellung/Position/Conexión Schaltwerte/Switching values/ ..ein/conex.°C Valeurs de commutation/Desconex. ..aus"/descon. (..abtaven' od) ..alarm'	RANCO K59/p1777 +3.5 +3.5 -31 -21		
Füllmenge/Fill. quantity/Charge/Carga R600	g	65	
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W	247	
Heizung/Heater/Chauflage/Resistenc.descong. Widerstand/Resistance/Resistencia Leistung/Power/Puissance/Potencia	KW W	267	81 4
Ventilador/Blower/Ventilateur/Ventilador Widerstand/Resistance/Resistencia	KW	Verdichter	Verdampfer