





DE'LONGHI

INTRUSKA A EST TR EC680.R

Pos.	Code	Description
01	7313285179	COVER
02	5313210051	MEASURING SPOON
03	6013211221	Small one-cup
04	6013211231	Large two-cup filter
05	6013211981	Pod filter
06	7313285229	SUMP
07	6013213301	CUP PLATE
08	5313237951	FLOAT
09	5313237551	DRIP TRAY
10	5513220321	FROTHER
13	7313285479	KNOB
14	5313236101	TUBE(SIL PLAT) DI=4 DE=8 L=150
15	7313285189	ASS. CONTROL BOARD
16	5113210421	MICROSWITCH
17	7313281219	TAP
18	7313285219	WATER TANK
19	5313236371	PROFILE LEFT
20	5313223751	JOINT
21	535693	GASKET
22	5313231221	TUBE LOWER
23	5513270699	TUBE DISTRIBUTING
26	5313236361	PROFILE RIGHT
27	6113211501	SPRING
28	5913214431	PUSH BUTTON ON/OFF
29	5128109300	SWITCH
30	5313236391	GASKET
31	5313223411	TUBE (ELASTOSIL)DI=4 L=270
32	7313285109	TRAY
33	5332265100	TUBE (SIL NAT) DI=4 L=120
34	5313229731	FOOT
35	6132101300	CLIP
36	5313217701	O-RING D=3,85
39	7332128100	VALVE
40	5113211281	PUMP
41	5213211161	PROTECTOR
42	6113210761	SPRING
43	5332289700	VALVE

DE'LONGHI

INTRUSKA A EST TR EC680.R

44	621986	RING
45	5213214671	FLOWMETER
45	5213214671	FLOWMETER
46	537177	GASKET
47	5313221481	GASKET
48	5313222311	SUPPORT
49	5313221491	GASKET
52	6013211191	DIFFUSER
53	5013276119	POWER SUPPLY CORD
54	5313237781	RUBBER PAD
55	5217100200	SENSOR NTC
56	5013211961	WIRING
57	5032509200	CONNECTOR
58	5013276049	WIRING
59	5213217881	POWER BOARD
60	5513217391	GENERATOR
61	5332239300	SPACER
62	5313217691	O-RING D=4,5
65	6132112100	SPRING
66	6113211071	BRACKET
67	5332242400	CONNECTION
68	511876	TCO 192
69	6013211951	TCO BRACKET
70	5313218931	CONNECTION
71	5532118000	TUBE PTFE DI2-DE4 L=230 2BUSHES
72	5513213661	TUBE PTFE DI2-DE4 L=135 1BUSHE
73	5532111900	TUBE PTFE DI2-DE4 L=100 2BUSHES
74	6132101600	SPRING
75	5313222031	CONNECTOR