





























66









85
SERIE TUBI
TUBE SERIES

86

SERIE TUBI CON BOCCOLE
TUBE SERIES WITH BUSHES



Pos.	Code	Description
	5332224100	MOTOR BELT GRINDER
	5313224911	GASKET
	5313213291	COVER
001	5313221031	COVER DUST
002	5513214851	COVER
003	7313222201	COVER ASSEMBLY
004	5913212611	KNOB
005	5313218551	REAR PANEL
006	5513217011	SIDE LEFT
007	5313219211	TANK
009	5313213441	SWITCH HOLDER
010	5513217001	SIDE RIGHT
011	5313213321	COVER
012	7313212611	TANK
013	5313218571	FRONT PIECE
014	5313223071	DRAWER
015	5313218521	FRONT PIECE
016	6013211171	CUP PLATE
017	5313218581	TRAY
018	5313222641	FLOAT
019	5132112500	SWITCH
021	5313213551	TRAY
025	7313221121	CONTROL PANEL ASSEMBLY
026	5213214661	BOARD DISPLAY
027	5313213911	COVER
028	5313213901	TANK
029	6132106200	SPRING
030	5332227400	REGULATOR
031	5313223051	COVER
032	5313224281	HANDLE
033	5313217741	O-RING
034	9812631250	SCREW

Pos.	Code	Description
035	7313218741	TAP
036	5513214681	KNOB
037	5513214861	GLASS
038	7313218691	FROTHER
039	5313220031	O-RING
040	5313217751	O-RING
041	5332169300	TUBE LOWER
042	5313221171	FROTHER
047	5213211171	SENSOR REED
048	5213214041	POWER BOARD
049	5313215261	FOOT
050	5313213841	STOP
054	7313218501	DIFFUSER KIT
055	6113210131	SPRING
056	5313213241	RUBBER PAD
057	5313213191	LEVER
058	9812631250	SCREW
059	6032105300	DIFFUSER
060	5332139600	STOPPER
061	5332139500	VALVE
062	6132112200	SPRING
063	5332149100	O-RING
064	5313213211	PISTON
065	5313227651	COVER
066	7313225061	COMPLETE GRINDER
070	9812631250	SCREW
071	5313213591	STOPPER
072	7313212631	TROLLEY
073	7313214521	REGULATOR
074	5313213431	RUBBER PAD
075	7313225981	TRANSMISSION KIT
076	5213211081	BOARD

Pos.	Code	Description
077	5132110500	MICROSWITCH
078	7313217261	MOTOR ASSEMBLY
079	5213213971	HALL SENSOR
080	5332170600	BELT
081	5313215271	TUBE
082	5132104100	MICROSWITCH
083	5332149100	O-RING
084	5313217601	FILTER
085	7313217301	VALVE
086	5332199500	TUBE DI=4 L=150
086	5313217861	TUBE DI=3 DE=5,5 L=145
086	5313217871	TUBE DI=3 DE=6 L=200
087	5513212891	TUBE
087	5513212871	TUBE PTFE DI2-DE4 L=97 2BUSHES
087	5513212901	TUBE PTFE DI2-DE4 L=290 2BUSHES
087	5513212881	TUBE PTFE DI2-DE4 L=270 2BUSHES
088	5313217701	O-RING D=3,85
089	6132101300	CLIP
090	5113210051	PUMP
091	5513211371	REGULATOR
092	5313230671	SUPPORT
093	5213211181	SENSOR NTC
094	5332239300	SPACER
095	5313217691	O-RING D=4,5
096	6113210021	SPRING
097	7313212561	VALVE
098	5113210211	SPRING MICROSWITCH
099	5213214671	FLOWMETER
100	5332239200	CONNECTOR
101	5213211161	PROTECTOR
102	5513214291	GENERATOR
103	5013251391	WIRING TCO

0132213027

DE'LONGHI "A/EST/INT/RU/SKA" ECAM22.110.B

ECAM22.110.B

Pos.	Code	Description
104	5013251401	WIRING TCO
105	5513214661	SLIDER