



Position	Code	description
000	FL304165	ANTI-DRIP BLOCK
	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
001	FL3041452	SUPPORT BASE AEROCCINO D
003	FL3040832	BOTTOM
004	FL3040822	SUPPORT BASE AEROCCINO D
005	FL304903	FOOT
006	FL29905	STOP
007	FL36262	BALL
008	FL36268	SUPPORT
009	FL3040552	WATER TANK BASE
010	FL29400	WATER CONNECTOR
011	FL18280	FILTER
012	FL304616	BRACKET
013	FL304084	CABLE GROMMET
014	FL95811	GRID
015	FL29903	SCREW
016	FL304139	FLOWMETER
017	FL95813	TANK
018	FL95814	WATER TANK COVER
019	FL304627	BOARD CABLE
020	FL3041582	FRONT PIECE
021	FL3040112	INSERT
022	FL304141	COVER
023	FL304014	RUNNER
024	FL304012	SUPPORT
025	FL304065	RUNNER
026	FL304657	RUBBER PAD
027	FL304063	SPRING
028	FL304915	SCREW
030	FL3040972	PUSH BUTTON
031	FL304060	RUNNER
032	FL304609	SUPPORT
033	FL304057	PCB
036	FL304142	PCB
037	FL304047	SUPPORT
038	FL304048	SUPPORT

039	FL304049	RUNNER
040	FL304645	DISPLAY
041	FL304901	PCB COVER
042	FL304051	RUNNER
043	FL304646	DISPLAY
044	FL304020	PUSH BUTTON RING
045	FL3040462	REAR PANEL
046	FL3040332	LEFT COVER
047	FL3040352	RIGHT COVER
049	FL304021	COVER
050	FL304074	SUPPORT
051	FL304031	COVER
052	FL304108	LENS
053	FL304092	SUPPORT
054	FL304036	SUPPORT
055	FL304072	LEVER
056	FL304073	SPRING
057	FL304655	CAPSULE IDENTIFICATION WIRING
058	FL96136	FRONT PIECE
058	FL95816	FRONT PIECE
059	FL96137	FRONT PIECE
059	FL95817	CAPSULE CONTAINER
060	FL304150	CLIP
061	FL95860	DRIP TRAY
062	FL95821	CUP HOLDER
063	FL304166	BODY
063	FL304093	BODY
064	FL304078	BODY
065	FL304010	UPPER BODY
066	FL29206	CAM
067	FL304910	TUBE
068	FL304107	CONNECTOR
069	FL304911	TUBE
070	FL3049095	PUMP
071	FL304652	PUMP WIRING
072	FL304040	SUPPORT
073	FL304041	SUPPORT
074	FL304053	SPRING

075	FL304042	TUBE
076	FL304126	CLIP CLAMP RING
077	FL304127	CLIP CLAMP RING
078	FL304134	VALVE
079	FL304043	TUBE
080	FL304067	WATER OUTLET
081	FL3041110	BOILER (220V-240V)
081	FL3041111	BOILER (220V-240V)
082	FL3003301	PUMP
083	FL304106	SPRING
084	FL304038	SUPPORT
085	FL29241	INSULATOR
086	FL29145	HIGH PRESSURE CONNECTOR
088	FL29907	O-RING
089	FL29242	SLEEVE
090	FL29908	GASKET
091	FL29902	SCREW
092	FL29123	TMBU
093	FL304664	MOTOR
094	FL29307	GEAR
095	FL29910	O-RING
096	FL2912452	CAM
097	FL2912552	CAM
098	FL29320	RING
099	FL304070	DRIP STOP
100	FL304085	COVER
101	FL304069	COVER
102	FL304068	SUPPORT
103	FL3046661	(THERMOBLOCK)
104	FL3041221	PCB
105	FL29915	CONNECTOR
106	FL95856	AEROCCINO 3 (D)
110	FL3049001	POWER SUPPLY CORD PLUG (INT)