


# 11 EXPLODED VIEW

## 11-1 THE EXPLODED VIEW OF CABINET ASSEMBLY

■ GK708E / GK710E / GK712E


○ : Non-service part

● : Service part




■ GK708EN / GK710EN / GK712EN

○ : Service Part  
 ○ : Non-Service Part




# 11-2 THE EXPLODED VIEW OF CONTROL PANEL & DISPENSER ASSEMBLY



# 11-3 THE EXPLODED VIEW OF DRUM & TUB ASSEMBLY

■ GK708E / GK710E / GK712E

- : Non-service part
- : Service part



■ GK708EN / GK710EN / GK712EN

- : Service Part
- (dashed) : Non-Service Part

