



11. EXPLODED VIEW

11-1. THE EXPLODED VIEW OF CABINET ASSEMBLY


○ : Non-service part
 ○ : Service part




■ WD(M)-8074F(H)B, WD(M)-1074(6)F(H)B, WD(M)-1174(6)F(H)B, WD(M)-1274(6)F(H)B, WD(M)-1374(6)F(H)B
 WD-8078FHB, WD-1078FHB, WM-1171(6)FHB, WM-1371(6)FHB, WD-1271FB(B), WD-1071FB(B)



11-2 THE EXPLODED VIEW OF CONTROL PANEL & DISPENSER ASSEMBLY



11-3 THE EXPLODED VIEW OF DRUM & TUB ASSEMBLY



■ WD(M)-8074F(H)B, WD(M)-1074(6)F(H)B, WD(M)-1174(6)F(H)B, WD(M)-1274(6)F(H)B, WD(M)-1374(6)F(H)B
 WD-8078FHB, WD-1078FHB, WM-1171(6)FHB, WM-1371(6)FHB, WD-1271FB(B), WD-1071FB(B)

