






Gebrauchsanweisung
59 0999
(ES)

- 1) 17 1312
- 2) 42 4340
- 3) 43 8723
- 4) 49 5511
- 5) 16 5552
- 6) 36 9906
- 7) 42 4825
- 8) 42 4398
- 9) 42 4801
- V01
- 42 8184
- V02
- 10) 36 9820
- 11) 36 6905



- 1) 21 6413
- 2) 17 1321
- 3) 42 6286
- 4) 35 6211



	V01	V02	
Pos.	Danfoss		
	NLE13KK3		
1	14 3864		
2	42 0376		
3	35 4158		
4	16 3427		
5	49 4671		
6	17 1318		
7	17 1519		
8	18 1014		
9	42 6296	16 5570	
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER				
Verdichter/Compressor/Kompresör		Danfoss		
Typ/Type/Tip		NLE13KK3		
Förderleistung/Delivery/Verim/h				
Anlaufstrom/Starting current/Giris akimi		A	7	
Widerstand/Resistance/Rezistans Ha/		Ω	13.2	
Hi/aux.			17.6	
Temp.Reyler/Thermostat/Termostat		Elektronisch		
Typ/Type/Tip				
Reglerstellung/Position/Termostat pozisyonu				
Schaltwerte/Acma kapama degerleri		..ein/acma °C		
Valeurs de commutation/Termostat degeri		..aus"/kapama		
(..abtaven' od)		..alarm'		
Füllmenge/Fill. quantily/ Dolum miktari		R600a	g	42
Anschlusswert/Comm. load/Giris gucu		W	150	
Heizung/Heater/Rezistans		Verdampfer	Ablaufrinne	Klappe
Widerstand/Resistance/Direnc		Ω		4
Leistung/Power/Guc		W	147	64
Ventilador/Blower/Vantilatör		Verdampfer		
Widerstand/Resistance/Rezistans		Ω		
Magnetventil/Magnetic valve/Manyetik valf				
Widerstand/Resistance/Rezistans		Ω		
Spannung/Voltage/Gerilim		V		
Temp.Reyler/Thermostat/Termostat				

* Siehe Typenschild/Mamul etiketine bakiniz