

REF. DESIG.	PART NO.	DESCRIPTION
002B	4822 464 50994	CHASSIS, FRONT [01B/02B/05B]
002B	4822 464 51005	CHASSIS, FRONT [01G/02G]
003B	4822 444 40701	FRONT PANEL (BLK) [01B/02B/05B]
003B	4822 444 40696	FRONT PANEL (GLD) [01G/02G]
006B	4822 410 62898	BUTTON, D3
005B	4822 410 62898	BUTTON, OPEN/CLOSE (BLK)
006B	4822 410 62898	BUTTON, OPEN/CLOSE (GLD)
007B	4822 450 62145	WINDOW
008B	4822 459 11167	LEG, REAR
021B	4822 502 13315	PH.TAP SCREW
023B	4822 410 62744	BUTTON, POWER (BLACK)
045B	4822 410 62744	BUTTON, POWER (GOLD)
050B	4822 454 30491	ESCUTCHEON [01B/02B]
050B	4822 454 30494	ESCUTCHEON [01G/02G]
003D	4822 502 12511	B.T.SCREW (W/W)
009G	4822 462 42045	LEG, FRONT
010G	4822 462 42048	LEG, REAR
021G	4822 502 12511	LINK, POWER (W/W)
025G	4822 403 70989	BUSHING, AC CORD [01B/01G]
911G	4822 532 60948	BUSHING, AC CORD BUSH [02B/02G/05B]
911G	4822 321 62203	JUMPER LEAD, SUMI-CARD 15P
911G	4822 321 62204	JUMPER LEAD, SUMI-CARD 37P/120MM
AW001	4822 321 10945	A.C.POWER CORD [01]
AW001	4822 321 10428	A.C.POWER CORD [02]
AW001	4822 321 11019	A.C.POWER CORD [05]
W101	4822 321 62203	JUMPER LEAD, SUMI-CARD 15P
WY01	4822 321 62204	JUMPER LEAD, SUMI-CARD 37P/120MM
001T	4822 736 21863	PACKING
J081	4822 265 10082	CONNECTIVE CORD, RCA 2P
J082	4822 265 10082	JACK, AC ADAPTER [01]
T100	4822 218 10527	IR COMANDER (RC-63CD)

REF. DESIG.	PART NO.	DESCRIPTION
002B	4822 464 50994	CHASSIS, FRONT
003B	4822 444 40702	FRONT PANEL, AL CD-43 (BLK)
005B	4822 410 62898	BUTTON, D3
006B	4822 410 62899	BUTTON, OPEN/CLOSE (BLK)
007B	4822 450 62155	WINDOW
008B	4822 459 11167	BADGE
021B	4822 502 13315	B.T.SCREW (W/L)
023B	4822 410 62744	PH.TAP SCREW
045B	4822 410 62744	BUTTON, POWER (BLACK)
050B	4822 454 30491	ESCUTCHEON
003D	4822 502 12511	B.T.SCREW (W/W)
009G	4822 462 42045	LEG, FRONT
010G	4822 462 42048	LEG, REAR
021G	4822 502 12511	B.T.SCREW (W/W)
025G	4822 403 70989	LINK, POWER SW.
911G	4822 532 61184	BUSHING, AC CORD [01B]
911G	4822 532 60948	BUSHING, AC CORD BUSH [02B/05B]
AW001	4822 321 10945	A.C.POWER CORD [01B]
AW001	4822 321 10428	A.C.POWER CORD [02B]
AW001	4822 321 11019	A.C.POWER CORD [05B]
W101	4822 321 62203	JUMPER LEAD, SUMI-CARD 15P
WY01	4822 321 62204	JUMPER LEAD, SUMI-CARD 37P/120MM
001T	4822 736 21863	PACKING
J081	4822 265 10082	CONNECTIVE CORD, RCA 2P
J082	4822 265 10082	JACK, AC ADAPTER [01B]
002B	4822 464 50994	CHASSIS, FRONT
003B	4822 444 40695	FRONT PANEL, AL CD-43 (BLK)
005B	4822 410 62898	BUTTON, D3
006B	4822 410 62899	BUTTON, OPEN/CLOSE (BLK)
007B	4822 450 62145	WINDOW, CD-53/63 WITH REMOTE
008B	4822 459 11167	BADGE
021B	4822 502 13315	B.T.SCREW (W/L)
023B	4822 410 62744	PH.TAP SCREW
045B	4822 410 62744	BUTTON, POWER (BLACK)
050B	4822 454 30491	ESCUTCHEON [01B/02B]
003D	4822 502 12511	B.T.SCREW (W/W)
009G	4822 462 42045	LEG, FRONT
010G	4822 462 42048	LEG, REAR
021G	4822 502 12511	B.T.SCREW (W/W)
025G	4822 403 70989	LINK, POWER SW.
911G	4822 532 61184	BUSHING, AC CORD [01B]
911G	4822 532 60948	BUSHING, AC CORD BUSH [02B/05B]
AW001	4822 321 10945	A.C.POWER CORD [01B]
AW001	4822 321 10428	A.C.POWER CORD [02B]
AW001	4822 321 11019	A.C.POWER CORD [05B]
W101	4822 321 62203	JUMPER LEAD, SUMI-CARD 15P
WY01	4822 321 62204	JUMPER LEAD, SUMI-CARD 37P/120MM
001T	4822 736 21863	PACKING
J081	4822 265 10082	CONNECTIVE CORD, RCA 2P
J082	4822 265 10082	JACK, AC ADAPTER [01]
T100	4822 218 10527	IR COMANDER (RC-63CD)

