


19 Exploded View and Replacement Parts List

19.1. Indoor Unit




Note

The above exploded view is for the purpose of parts disassembly and replacement.
The non-numbered parts are not kept as standard service parts.

19.2. Outdoor Unit

19.2.1. CU-E7JKE CU-E9JKE CU-E12JKE CU-E15JKE-1 CU-E7JKE-3 CU-E9JKE-3 CU-E12JKE-3



Note

The above exploded view is for the purpose of parts disassembly and replacement.
The non-numbered parts are not kept as standard service parts.