

18 Exploded View and Replacement Parts List

18.1. Indoor Unit



18.2. CU-RE18JKE-1



Note:

The above exploded view is for the purpose of parts disassembly and replacement.

The non-numbered parts are not kept as standard service parts.