


TAPE MECHANISM A - PLAY

MECHANICAL PARTS - PLAY MECHANISM

1	996500002313	Play Head (Non-Autoreverse deck)
1	996500002321	Play Head (Autoreverse deck)
12	482240210972	Pinch Arm Assembly R
23	996500002314	Coil Assembly
32	482252811209	Flywheel Assembly RV
42	996500002315	Belt AF (Autoreverse deck)
42	996500002718	Belt AF (Non-autoreverse deck)
69	482249211761	Spring
102	482253212931	Washer
103	482253212932	Washer
104	482253212933	Washer

Note: Only the parts mentioned in the list are normal service spare parts.




TAPE MECHANISM B - RECORD/PLAYBACK (Non-Autoreverse version)

MECHANICAL PARTS - REC/PB MECHANISM

1	996500002313	Play Head
3	996500002600	Head, Erase
12	482240210972	Pinch Arm Assembly R
23	996500002314	Coil Assembly
32	482252811209	Flywheel Assembly RV
44-2	996500002317	Flex Socket 14 Pin
44-3	996500002320	Photo Interrupter
44-4	482205016801	680R 1% 0.4W
44-6	996500002318	Leaf Switch
44-7	996500002319	Mode Switch
59	996500002719	Belt BF (Large)
69	482243211761	Spring
102	482253212931	Washer
103	482253212932	Washer
104	482253212933	Washer

Note: Only the parts mentioned in the list are normal service spare parts.







TAPE MECHANISM B - RECORD/PLAYBACK (Autoreverse version)


MECHANICAL PARTS - REC/PB MECHANISM

12	482240210972	Pinch Arm Assembly R
23	996500002314	Coil Assembly
32	482252811209	Flywheel Assembly RV
39	996500002322	Belt AF
44-2	996500002317	Flex Socket 14 Pin
44-3	996500002320	Photo Interrupter
44-4	482205016801	680R 1% 0.4W
44-6	996500002318	Leaf Switch
44-7	996500002319	Mode Switch
45	996500002323	Rec/Pb Head Assembly
50	482240210973	Pinch Arm Assembly L
54	996500002324	Flywheel Assembly L
69	48224921-761	Spring
73	48224921-762	Spring
101	996500002325	Washer
102	482259212931	Washer
103	482259212932	Washer
104	482259212933	Washer
107	996500002326	Washer
109	996500002327	Washer

Note: Only the parts mentioned in the list are normal service spare parts.







MECHANICAL PARTSLIST 3CDC-99 MODULE

	4822 390 10136	POLYLUB GLY801 (GREASE)	43	4822 528 10937	PULLEY
3	4822 463 11008	GUIDE LEFT	44	4822 522 10493	IDLER WHEEL
4	4822 463 11009	GUIDE RIGHT	45	4822 358 10115	BELT
21	4822 441 11615	DRAWER	46	4822 466 10735	ECCENTRIC GEAR WHEEL
22	4822 402 10088	BRACKET TUMBLER	50	4822 532 12364	WASHER
38	4822 502 12548	SCREW M2,6X3,5	51	4822 532 12364	WASHER
39	4822 502 12548	SCREW M2,6X3,5	52	4822 532 12364	WASHER
40	4822 463 11011	SLIDE	53	4822 532 12364	WASHER
41	4822 522 10509	CONTROL DISC	35	4822 361 10753	CARROUSEL MOTOR
42	4822 522 10492	GEAR WHEEL	70	4822 361 10753	CARROUSEL MOTOR

continued on next page