













PARTS LIST

Location No.	TSB P/N	Reference No.	Description	
1	AH700673	SUBSD590TE/BFP	FRONT PANEL ASS'Y FOR MODEL SD590E-K-TB/TE, SD591E-K-TF, SD900-K-TR/TY	
2	 AH700686	038-SD7200W002	FRONT PCB ASS'Y w/USB	
3	 AH700658	SUBSD490ETBPWR	POWER PCB ASS'Y APS-D0092D-G (FOR BSI AC CORD)	For SD590EKB
3	 AH700659	SUBSD490ETEPWR	POWER PCB ASS'Y APS-D0092D-G (FOR VDE VERSION)	For SD590EKE/SD591EKF
4	AH700650	600-SD7221W001	TOP COVER SD72-21, T=0.4mm CR FREE, E.G. STEEL, w/CABINET BLACK 2007 SPRAY	
5	 AH700660	SCA-SD490EE	SCART PCB ASS'Y (SCART PORTION OF MODEL SD490E@)	
6	 AH700674	MN--SD590EE	MAIN PCB ASS'Y (MAIN PORTION OF MODEL SD590E@ SERIES) (FOR ZORAN V976)	
7	 AH700662	SUBLSDSD7200E	DVD MECHA ASS'Y	
8	AH700585	163-000076W006	TRAVERSE MECHA ASS'Y (SAMSUNG DVD MECHANISM CMS-S76RFS2 MAGNET CHUCK)	
9	AH700675	043-000350W021	REMOTE CONTROL HANDSET SE-R0350, w/WEEE MARK/CHA/HELPLINE STICKER	For SD590EKB
9	AH700676	043-000350W010	REMOTE CONTROL HANDSET SE-R0350, w/WEEE MARK/CHA	For SD590EKE/SD591EKF
10	 AH700677	811-S59E91W011	OWNER'S MANUAL - ENGLISH	For SD590EKB
11	 AH700678	811-S59E91W020	QUICK START GUIDE - ENGLISH	For SD590EKB/SD591EKF
12	 AH700679	811-S59E91W041	OWNER'S MANUAL - ENGLISH & GERMAN	For SD590EKE
13	 AH700680	811-S59E91W050	OWNER'S MANUAL (COMBINED) - 14 LANGUAGE	For SD590EKE
14	 AH700681	811-S59E91W032	OWNER'S MANUAL - FRENCH	For SD591EKF

SAFETY PRECAUTION

The parts identified by  mark are critical for safety. Replace only with part number specified. The mounting position of replacement is to be identical with originals. The substitute replacement parts which do not have the same safety characteristics as specified in the parts list may create shock, fire or other hazards.

EXPLODED VIEW

