


This diagram illustrates the exploded view of a washing machine, showing the main body, door, and various internal components. The parts are labeled with numbers, including:

- Top Panel:** 030 0, 743 0, 241 6, 241 2, 241 0, 265 2, 265 0, 241 3, 241 1.
- Door and Hinge Assembly:** 910 0, 701 0, 701 2, 034 1, 034 0, 022 0, 964 1, 993 0, 716 0, 781 0, 531 0, 531 1, 131 0, 910 4, 263 0, 726 3, 726 2, 722 2, 241 8, 722 0, 722 2, 242 2, 242 1, 242 0, 242 3.
- Internal Components:** 061 0, 024 0, 781 1, 701 1, 571 0, 714 0, 710 2, 710 3, 011 0, 022 2, 783 4, 761 1, 901 0, 581 0, 791 3, 575 0, 710 0, 791 2, 616 0, 755 2/3, 743 1, 490 0, 763 0, 612 0, 910 6, 003 0, 022 1, 751 2, 791 0, 751 0, 783 6, 714 2, 781 2, 781 3, 794 1, 430 0, 721 3, 721 4, 791 6, 791 5, 691 0, 783 0, 901 3, 571 2, 004 1, 004 0, 623 0, 756 0, 521 0.
- Motor and Drive Assembly:** 420 0, 405 1, 405 0, 901 2, 583 0, 450 0, 901 2, 755 0, 901 1, 791 5, 691 0, 723 0, 726 1, 723 2, 723 1, 723 3, 721 1, 721 2, 721 0, 762 0, 243 3, 243 0, 901 5, 783 5, 901 6, 993 5.
- Other Components:** 034 0, 022 0, 964 1, 131 0, 263 1, 261 1, 261 2, 261 0, 964 0, 003 0, 022 1, 755 2/3, 743 1, 490 0, 763 0, 612 0, 910 6, 003 0, 022 1, 751 2, 791 0, 751 0, 783 6, 714 2, 781 2, 781 3, 794 1, 430 0, 721 3, 721 4, 791 6, 791 5, 691 0, 783 0, 901 3, 571 2, 004 1, 004 0, 623 0, 756 0, 521 0.

The diagram also includes a small inset showing a control panel with a digital display and buttons.

VUE ECLATEE



08000016