


Spare Part List

Pos	12NC	Description
001 3	4812 404 48784	Bracket foot
004 0	4812 440 11486	Drip tray assy
011 0	4812 505 18382	Foot long, adjustable
022 0	4812 440 11487	Side panel left
022 1	4812 440 11488	Side panel right
024 0	4812 440 11496	Panel rear
040 1	4812 417 18836	Hinge right
040 2	4812 417 18835	Hinge left
040 3	4812 417 19416	Support 45cm Hinge
044 0	4812 492 38404	Spring f.door
047 0	4812 404 48864	Bearing,roll Hingey
047 1	4812 404 48735	Brake Door
047 2	4812 404 68032	Hook Hinge left
047 3	4812 404 68033	Hook Hinge right
053 0	4812 440 89149	Plinth metal 45cm
065 0	4812 466 48114	Insulation Cabinet
103 0	4812 440 11491	Door outer painted
105 0	4812 273 18061	Fastener door
120 0	4812 440 11499	Door inner
120 1	4812 440 11493	Batten
123 0	4812 466 48107	Insulation door
130 0	4812 417 58397	Tilt lock cpl.
131 0	4812 401 18578	Hook Lock
191 0	4812 466 68881	Gasket Door, Frame
191 1	4812 466 68732	Sealing door
191 2	4812 466 68733	Sealing door
192 0	4812 466 68882	Gasket door lower
200 1	4812 466 88913	Angle iron upper left
200 2	4812 466 88914	Angle iron upper right
241 1	4812 404 48825	Shelf
241 3	4812 528 88131	Wheel basket upper (set)wh
241 4	4812 458 19335	Basket upper w. roller
242 0	4812 458 19336	Basket lower/rack flex cpl.
242 1	4812 528 88132	Wheel basket lower Kit wh
242 3	4812 458 19341	Support plate lower rack
242 5	4812 404 68069	Bearing Support plate
242 7	4812 404 68071	Clip fix Support plate
243 0	4812 458 19329	Cutlery basket wh
243 3	4812 458 19331	Grille wh
261 0	4812 462 38075	Rail telescope, inner
261 1	4812 462 79745	Cap rail
261 2	4812 462 79746	Cap rail ahead
301 0	4812 453 73281	Control panel DWH C
332 0	4812 410 29389	Button cap on/off IX
332 1	4812 410 29432	Button start-stop/cancel cap
332 2	4812 410 29433	Button progr.
332 3	4812 410 29393	Spring Button
351 0	4812 381 28087	Light guide
400 0	4812 361 58438	Motor + spraypump
400 1	4812 846 78001	Cap fixation


Pos	12NC	Description
400 2	4812 401 18815	Bracket Motor/SP
400 3	4812 401 18491	Damper circulation pump
400 4	4812 401 18816	Bracket Motor/SP kit
400 5	4812 401 18818	Damper Motor+SP
420 0	4812 121 18283	Capacitor 3 μ
421 0	4812 121 18241	Interf.filter
430 0	4812 360 18566	Pump,draining therm.protect.
450 0	4812 259 28874	Heating element dmr 32mm
450 4	4812 530 29415	Hose Pump-Heating element
480 0	4812 321 28463	Cable harness
490 0	4812 905 08124	Cable mains Euro 220-230v
490 1	4812 321 28461	Strain relief
505 0	4812 218 38446	Control board B345
505 1	4812 452 15849	Holder (CB)front (45)
505 2	4812 452 15945	Holder (CB)back 45 cm
506 0	4812 452 15977	Display
506 1	4812 452 15853	Holder Display above
506 2	4812 452 15854	Holder Display lower
571 0	4812 281 28428	Inlet valve
575 0	4812 281 28408	Valve magnet regener.
583 0	4812 271 28584	Flowmeter
583 1	4812 404 68066	Holder Flowmeter
616 0	4812 281 18051	Contact reed salt
616 1	4812 281 18068	Contact reed rinsing agent
621 0	4812 276 18505	Switch on/off
631 1	4812 271 28452	Switch overflow
633 0	4812 271 38502	Microswitch door
680 0	4812 418 68314	Combidosage 7037 w.reed 2008
680 1	4812 466 68794	Gasket
680 2	4812 271 58168	Switch,thermal
681 1	4812 466 68811	Gasket
692 0	4812 282 68054	Feeler NTC
701 0	4812 530 29429	Hose inlet Reflex
701 1	4812 404 78606	Yoke
701 3	4812 480 58104	Filter
710 0	4812 418 68384	Monoblock cpl.w.Reed
710 2	4812 526 48229	Threaded ring grey
710 3	4812 466 68809	Gasket
710 6	4812 466 68646	Gasket Regeneration valve
714 0	4812 418 68209	Lid Monoblock
716 0	4812 418 68386	Reg.dosage
716 1	4812 466 68647	Gasket Reg.dosage
716 2	4812 462 79948	Cover Reg.dosage
716 9	4812 530 29417	Hose
721 1	4812 360 68823	Spray arm lower. grey
721 5	4812 401 48591	Clamp Water collector
722 0	4812 360 68824	Spray arm upper grey
722 1	4812 360 68825	Spray arm upper set wh
723 2	4812 360 68826	Spray arm Ceiling
723 4	4812 310 19114	Douche ceiling KIT

Pos	12NC	Description
726 0	4812 360 68828	Tube assembly cpl.grey
726 1	4812 256 98047	Support Spray arm upper
726 2	4812 256 98048	Holder Spray arm upper
726 3	4812 466 28126	Gasket spray feedhose
726 4	4812 466 68648	Holder spray arm hose
726 5	4812 466 68649	Guide
726 6	4812 360 68829	Spray arm Tuber
751 0	4812 418 18578	Water collector
755 0	4812 530 29418	Bend
756 0	4812 271 18017	Switch over flow
756 1	4812 548 28035	Tray leak
761 0	4812 480 58374	Sieve fine metal
761 1	4812 480 58375	Filter Support
762 0	4812 480 58376	Filter micro
763 0	4812 480 58377	Filter coarse
764 0	4812 480 58378	Filter cpl.
781 0	4812 530 29419	Hose draining
783 1	4812 530 29426	Hose Pump/sump
783 4	4812 530 58169	Hose
783 5	4812 530 29424	Hose Flowm./Reg.d.
783 6	4812 530 58174	Hose
783 7	4812 530 29422	Hose Reg.dosage
783 9	4812 530 29423	Hose Reg.d.-sump
784 1	4812 530 58129	Hose
784 2	4812 530 58175	Hose
791 0	4812 630 58103	O-Ring Suction pipe
901 2	4812 401 18821	Clamp hose
901 3	4812 401 18822	Clamp hose
901 4	4812 401 18494	Strap 47
901 5	4812 401 18495	Strap 40
901 6	4812 401 18496	Strap 15,9
901 8	4812 401 18819	Strap
902 1	4812 905 08787	Fastener f.build-in models
910 1	4812 502 18473	Screw PT 4x18
910 2	4812 502 18456	Screw 4x18
910 4	4812 502 18457	Screw 4x14
910 5	4812 502 18458	Screw 4x16
910 7	4812 462 79949	Stopper Door,inner
911 3	4812 502 18536	Screw M4X8
911 4	4812 502 18504	Screw
911 5	4812 502 18463	Screw 3,9x19
911 8	4812 502 18466	Screw
915 3	4812 502 18472	Screw M5x8
915 4	4812 846 78003	Cap screw wh
915 5	4812 404 18146	Screw 5x22
921 3	4812 526 48073	Washer
964 0	4812 466 68884	Gasket Cabinet upper
964 1	4812 466 68885	Gasket Cabinet left
964 2	4812 466 68886	Gasket Cabinet right
993 0	4819 530 29028	Bow


Pos	12NC	Description
993 5	4822 532 80216	Funnel salt
994 0	4812 310 88429	Fastener kit(FD-IKEA,n.shown)

Exploded View

1799818030

Exploded View

1799827036

Exploded View

1799838030